


**WIRED REMOTE CONTROL • CONTROL REMOTO CON CABLES • TELECOMANDO CABLATO •
KABELFERNBEDIENUNG • CONTROLO REMOTO COM FIOS • BEDRADE AFSTANDSBEDIENING**



Pursuant to at the directive 2004/108/EC, article 9(2)
Panasonic Testing Centre
Panasonic Service Europe, a division of
Panasonic Marketing Europe GmbH
Winsbergring 15, 22525 Hamburg, F.R. Germany

1



Start/stop the operation.
Inicie/detenga el funcionamiento.
Avviare/arrestare l'apparecchio.
Schalten Sie das Gerät ein bzw. aus.
Ligue/Desligue a unidade.
Start/stop het apparaat.


2



Inverter/Heat-pump
model



Cooling model



Select the desired mode.
Seleccione el modo deseado.
Selezionare la modalità desiderata.
Wählen Sie die gewünschte Betriebsart
aus.
Seleccione o modo de funcionamiento
pretendido.
Selecteer de gewenste stand.

3



Select the desired temperature.
Seleccione la temperature deseada.
Selezionare la temperatura desiderata.
Stellen Sie die gewünschte Temperatur ein.
Programa a temperatura desejada.
Stel de gewenste temperatuur in.

Matsushita Electric Industrial Co., Ltd.

Web Site: <http://www.panasonic.co.jp/global/>